

To assemble, connect the bottom corner connectors and feet together. Assemble the bungee-linked top and bottom horizontal tubes. Snap and connect the bottom horizontal tubes with the bottom corner connectors with matching labels. Then assemble the bungee-linked vertical tubes. Snap on the the remaining vertical tubes with the bottom corner connectors. Using the top corner connectors, connect the top horizontal tube to both vertical tubes to complete frame. Tilt or lay down frame to swiftly drape with the pillowcase graphic. Using the industrial-size-zipper, zip underneath the bottom tube, maximizing fabric tension and zip closed.