

BLADE PRO KIOSK

3RD PARTY DEVICE INSTALL




PC Power

*You may need to replace your existing PC power cable with one that has a smaller, low profile plug.

HDMI Cable

*HDMI 2.0 Default Port



Touch Interface USB Cable

*If unit is touchscreen

Exterior USB Extension Cable

*Optional use for easy access to internal USB Port

Mini PC / PC Stick / 3rd Party Device

*Attach to kiosk with heavy duty double-sided tape or hook and loop fastener